Weighing Platform



PBA639/PBD659

Exceptional Hygienic Design Pre-Calibrated, Ready to Use Durable Construction Hazardous Area Approved



Simplified Hygienic Weighing

Designed for Wet Environments



PBA639/PBD659 Weighing Platforms Cleaning and Compliance Made Easy

In regulated, hygienic environments, ease of equipment sanitation is as important as the operational performance. It is becoming increasingly important to streamline cleaning processes to not only eliminate contamination risk but also maximize productivity. The PBD659 /PBA639 stainless steel weighing platforms enable you to address these challenges with an optimized hygienic design.



Maximize equipment uptime

Protect your operation with the scale designed to withstand impacts and ensure peak performance in challenging environments, enabling increased uptime, reduced maintenance and maximized equipment longevity.



Accelerate cleaning speed

Easily achieve higher hygienic standards and boost cleaning speed by up to 40% with less effort. The innovative open platter and stainless steel design prevent moisture accumulation and allow you to eliminate contamination risk in regulated environments.



Prevent bad batches

The smart load cell used within the PBD platforms actively corrects and compensates for measurement errors caused by external and internal factors, which improves accuracy by up to 100% to prevent bad batches and reduce product waste.

Meet the specific needs of your regulated environment:



Pharmaceutical industry

mize cleaning time.



Food and beverage industry The rapid advancements and increasing demand in the food and beverage industry require maximum process efficiency and reliable measuring results. To ensure you meet these requirements, these platforms offer durable construction, IP68/IP69k load cell protection, and easy-to-clean surfaces.



Biotech industry

ardous area use.

Chemical industry

Hygienic equipment is required in biotech environments to avoid contamination and extended downtime due to long cleaning cycles. The hermetically sealed load cell and unique hygienic design allow you to spend less time on washdown processes and to boost your productivity.

We offer global and local partnership, no matter where you do business.

Whether you are a multinational business or a systems integrator serving customers worldwide, our globally approved weighing platforms enable you to standardize your weighing solutions to minimize procurement and engineering hours and deliver a reliable value to your customers or production facilities worldwide. Our comprehensive consulting and extensive weighing portfolio are available to help you simplify your job.



For pharmaceutical manufacturers, hygiene and accuracy are paramount. The PBA639/ PBD659 hygienic weighing platforms prevent contamination and ensure accurate measurements so that you can deliver high quality products, boost throughput, and mini-

In chemical production, corrosive materials and safety are top concerns. Maximize production uptime and ensure compliance in hazardous areas with these high-grade stainless steel platforms that are globally approved for Zone 2/22 and Zone 1/21 haz-

Achieve Extraordinary Hygiene Engineered for Easy Cleanability

Manufacturing high quality products requires state-of-the-art equipment to ensure that your processes not only adhere to strict regulations but also that your final product is safe and meets your customers' expectations. This platform strictly adheres to hygienic design guidelines, facilitates quick and easy cleaning, and meets higher accuracy standards to optimize your processes and reduce costs.

Learn more about the PBA639/PBD659 . Visit the page: www.mt.com/PBA639-PBD659









Click to show the platter on the platform frame

Open platter

Closed platter

Technical Specifications - Metric

Standard Configurations PBD659 Smart and PBA639 Analog Weighing Platforms

Metric (kg/m)

Model	Platform Size	Maximu	m Capacity						
PBD659/PBA639-QA	228 × 228 [mm]	3 kg	6 kg						1
PBD659/PBA639-A	240 × 300 [mm]	3 kg	6 kg	12/15 kg					
PBD659/PBA639-QB	305 × 305 [mm]			12/15 kg	30 kg	60 kg			
PBD659/PBA639-BB	300 × 400 [mm]				30 kg	60 kg			
PBD659/PBA639-B	400 × 500 [mm]				30 kg	60 kg	120/150 kg		
PBD659/PBA639-BC	500 × 650 [mm]					60 kg	120/150 kg	300 kg	
PBD659/PBA639-CC	600 × 800 [mm]					60 kg	120/150 kg	300 kg	600 kg

Load cell cable length: Optional 2.5 m or 5 m cable for PBA639; Standard 2.5 m cable for PBD659, and extension cables are in accessories.

Weights and Measures - Legal for Trade Data

OIML (International Organization of Legal Metrology)

OIML certification provides confidence that a weighing device complies with the OIML R76 regulation, which establishes the metrological characteristics required for weighing instruments and specifies methods and equipment for checking their conformity.

PBD659 - Smart Weighing Platform

		Maximum Capacity									
OIML / Metric (kg/m)	3 kg	6 kg	12 kg	30 kg	60 kg	120 kg	300 kg	600 kg			
Approved Accuracy Resolution Clas	s III Single Rar	nge - 1 × 6,0	000e (*3,0	00e)	<u> </u>						
Approved Readability (e min.)	[g]	0.5	1	2	5	10	20	50	200*		
Minimum Capacity	[g]	10	20	40	100	200	400	1,000	4,000		

PBA639 - Analog Weighing Platform

		Maximum	n Capacity						
OIML / Metric (kg/m)		3 kg	6 kg	15 kg	30 kg	60 kg	150 kg	300 kg	600 kg
Approved Resolution Class III Singl	e Range - 1×3	3,000e							
Approved Readability (e min.)	[g]	1	2	5	10	20	50	100	200
Minimum Capacity	[g]	20	40	100	200	400	1,000	2,000	4,000
Approved Resolution Class III Multi	-Range - 2 × 3,	000e							
Approved Readability (Max1/e1)	[kg/g]	n/a	3/1	6/2	15/5	30/10	60/20	150/50	300/100
Approved Readability (Max2/e2)	[kg/g]	n/a	6/2	15/5	30/10	60/20	150/50	300/100	600/200
Minimum Capacity	[g]	n/a	20	40	100	200	400	1,000	2,000

Weigh and Measure OIML General Thresholds

Preload Range	[%]	18% of Maximum Capacity
Zero Setting Range	[%]	2% of Maximum Capacity
Taring Range	[kg]	Subtractive from 0 to Maximum Capacitiy
Temperature Range	[°C]	-10°C+40°C

Glossary

Weighing Terms	Simple Definition
Readability	The smallest difference in mass that can be read on a weighing instrument. For instruments with a digital display, the readability is equal to the division value or actual scale interval of the display. Recommended readability (min.) is what is prescribed by the manufacturer; whereas, approved readability is prescribed (or mandated) by weights and measures authorities.
Resolution	Smallest difference between displayed indications that can be meaningfully distinguished - this is a non-technical expression for the number of scale intervals. Sometimes confused with readability.
Minimum Capacity	The lower range of a scale that should not be used, this range is mandated by weights and measures intended to eliminate excessive relative weighing errors. In industry, it is recommended to use minimum weight instead because it is considered a more accurate method that considers the customer's production tolerance.
Repeatability	Ability of a weighing instrument to provide results that agree one with the other when the same load is deposited several times in a practically identical way on the load receptor under reasonably constant test conditions. Repeatability is expressed as a standard deviation.
Error of Indication at full load / half load	The difference between the weight indicated on the display and the actual test weight (full load / half load) placed on the scale. The value represents the combined error of non-linearity, sensitivity offset and repeatability. Note: Sometimes this is wrongly referred to as sensitivity error, or span error.
Minimum Weight	Smallest (sample) weight required for a weighment to achieve a desired weighing tolerance. Weighing below the minimum weight threshold results in errors because the sample weight is too small to achieve the defined process tolerance.

Weighing - Performance Data

Performance data or typical values are determined in production with no wind drafts and no vibration. Typical values represent the statistical mean value of all measured devices.

PBD659 - Smart Weighing Platform

		Maximun	n Capacit	y					
Metric (kg/m)		3 kg	6 kg	12 kg	30 kg	60 kg	120 kg	300 kg	600 kg
Readabilites at max. Resolution (~60,0)00d/6,0	000e)							
Recommended Readability (min.)	[g]	0.05	0.1	0.2	0.5	1	2	5	10
Minimum Weight @ 1%	[g]	6	8.2	16.4	41	104	182	440	1360
Typical values			-					<u></u>	
Repeatability sd (at full load)	[g]	0.033	0.033	0.08	0.14	0.52	0.91	2.20	6.80
Error of indication typ. (at half load)	[g]	0.08	0.10	0.25	0.50	1.50	6.00	9.00	21.00
Error of indication typ (at full load)	[g]	0.11	0.12	0.40	0.80	1.20	5.00	6.00	16.00

Max. Preload for non-approved platforms without Weighing Platter

		Maximu	m Capacit	t y						Weight We	ighing Platter (kg)
Metric (kg/m)		3 kg	6 kg	12 kg	30 kg	60 kg	120 kg	300 kg	600 kg	Open	Closed
QA (228 x 228 mm)	[kg]	7.20	4.2							1.20	1.90
A (240 x 300 mm)	[kg]	7.20	4.2	9.2						1.50	2.40
QB (305 x 305 mm)	[kg]			8.5	28.5	38.5				1.80	2.80
BB (300 x 400 mm)	[kg]				28.0	38.0				2.30	3.50
B (400 x 500 mm)	[kg]				26.0	36.0	76.0			5.60	5.50
BC (500 x 650 mm)	[kg]					33.0	43.0	193.0		n/a	8.40
CC (600 x 800 mm)	[kg]					29.4	39.4	189.4	139.4	n/a	11.50 / 14.70*

PBA639 - Analog Weighing Platform

		Maximum	Capacity	1					
Metric (kg/m)		3 kg	6 kg	15 kg	30 kg	60 kg	150 kg	300 kg	600 kg
Readabilites at max. Resolution (~30,0	00d/2x	3,000e)							
Recommended Readability (min.)	[g]	0.1	0.2	0.5	1	2	5	10	20
Minimum Weight @ 1%	[g]	8.2	16.4	41	82	164	410	820	1640
Typical values		<u>^</u>	-			<u>.</u>	·	<u>.</u>	
Repeatability sd (at full load)	[g]	0.04	0.04	0.12	0.28	0.80	1.30	1.90	7.10
Error of indication typ. (at half load)	[g]	0.15	0.15	0.70	1.50	1.60	9.10	14.20	29.70
Error of indication typ (at full load)	[g]	0.15	0.15	0.60	1.00	1.30	7.00	10.90	24.80

Max. Preload for non-approved platforms without Weighing Platter

		Maximun	n Capacit	у						Weight Wei	ighing Platter (kg)
Metric (kg/m)		3 kg	6 kg	15 kg	30 kg	60 kg	150 kg	300 kg	600 kg	Open	Closed
QA (228 x 228 mm)	[kg]	7.2	4.2							1.2	1.9
A (240 x 300 mm)	[kg]	7.2	4.2	6.2						1.5	2.4
QB (305 x 305 mm)	[kg]			5.5	28.5	38.5				1.8	2.8
BB (300 x 400 mm)	[kg]				28.0	38.0				2.3	3.5
B (400 x 500 mm)	[kg]				26.0	36.0	46.0			5.6	5.5
BC (500 x 650 mm)	[kg]					33.0	93.0	193.0		n/a	8.4
CC (600 x 800 mm)	[kg]					29.4	89.4	189.4	139.4	n/a	11.5 / 14.7*



*600 kg Model

*600 kg Model


For more technical information see the user manual.





Technical Data

Platform Dimensions



Dimensions in mm of PBA639 and PBD659 models

Dimensions		a	b	C	d min.	е	f	g	h
QA	mm	178	228	70	110	178	228	21	40
A	mm	190	240	70	110	250	300	21	40
QB	mm	255	305	70	110	255	305	21	40
BB	mm	250	300	70	110	350	400	21	40
В	mm	350	400	83	126	450	500	21	40
BC	mm	450	500	90	134	600	650	21	40
CC	mm	550	600	90	134	750	800	21	40
CC [600 kg]	mm	550	600	94	140.5	750	800	21	40

Dimensions in inch of PBA639 and PBD659 models

Dimensions		a	b	C	d min.	е	f	g	h
QA	inch	7.01	8.98	2.76	4.33	7.01	8.98	0.83	1.57
A	inch	7.48	9.45	2.76	4.33	9.84	11.81	0.83	1.57
QB	inch	10.04	12.01	2.76	4.33	10.04	12.01	0.83	1.57
BB	inch	9.84	11.81	2.76	4.33	13.78	15.75	0.83	1.57
В	inch	13.78	15.75	3.27	4.96	17.72	19.69	0.83	1.57
BC	inch	17.72	19.69	3.54	5.28	23.62	25.59	0.83	1.57
CC	inch	21.65	23.62	3.54	5.28	29.53	31.5	0.83	1.57
CC [600 kg]	inch	21.65	23.62	3.70	5.53	29.53	31.5	0.83	1.57


Construction per plaform size



A = 240 × 300 mm / 9.5" × 11.8" $QA = 228 \times 228 \text{ mm} / 9" \times 9"$



BB = 300 × 400 mm / 11.8" × 15.7" QB = 305 × 305 mm / 12" × 12" B = 400 × 500 mm / 15.7" × 19.7"



PBA639

Ingress Protection	IP68/IP69k	
Material	Platform Frame: Stainless Steel (AISI304)	
	Load Plate: Stainless Steel (AISI304 or AISI31	6 optional)
	Feet: TPA (FDA approved) / Load Cell Cables:	PVC
Surface	Load Plate: Ra ≤0.8um	
oad Cell	Hermetically sealed, Stainless steel	
load Cell Cable Length	PBA639: Optional 2.5 m or 5 m PBD659: Standard 2.5 m, and extension cable	as are in the accessories
Compliance	Metrology	OIML Class III, NTEP Class III
	EMC	10 V/m
Scale Interface	Analog	
Operating Temperature	Compensated	-10°C to +40°C / 14°F to 104°F)
	Operation (Safe Area)	-20°C+65°C / -4°F+149°F
lazardous Area Approvals (Optional)	ATEX/IECEx	2G Ex ia C T6T4 Gb 2D Ex ia IC T80°C Db -40°C≤Ta≤60°C T5/T4; -40°C≤Ta≤40°C T6
		II 3G Ex ic IIC T6…T4 Gc -40°C≤Ta≤60°C T5/T4; -40°C≤Ta≤40°C T6 II 3G Ex ec IIC T6 Gc II 3D Ex tc IIIC T80°C Dc -40°C≤Ta≤60°C
	FMus	IS/I,II,III/1/ABCDEFG/T6T4 Class I, Zone 1, AEx ia IIC T6T4 Gb Class II,III, Zone 21, AEx ia IIIC T80°C Db -40°C≤Ta≤60°C T5/T4; -40°C≤Ta≤40°C T6'
		NI/I,II,III/2/ABCDEFG/T6 -40°C≤Ta≤60°C
	FMc	IS/I, II, III/1/ABCDEFG/T6T4 Class I, Zone 1, Ex ia IIC T6T4 Gb Class II, III, Zone 21, Ex ia IIIC T80°C Db -40°C≤Ta≤60°C T5/T4; -40°C≤Ta≤40°C T6'
		NI/I,II,III/2/ABCDEFG/T6 -40°C≤Ta≤60°C Class I, Zone 2, Ex ec IIC T6 Gc; Class II,III, Zone 22, Ex tc IIIC T80°C Dc
Suitable Indicators	Safe Area: all analoge Mettler-Toledo indicators	· · · · · · · · · · · · · · · · · · ·
	Hazardous area: select appropriate Ex Approve	d indicators per local Ex regulations

PBD659

Ingress Protection	IP68/IP69k		
Material	Platform Frame: Stainless Steel (AISI304)		
	Load Plate: Stainless Steel (AISI304 or AISI316 optional)		
	Feet: TPA (FDA approved) / Load Cell Cables: PVC		
Surface	Load Plate: Ra ≤0.8um		
Load Cell	Hermetically sealed, Stainless steel		
Compliance	Metrology	OIML Class III, NTEP Class III	
	EMC	10 V/m	
Scale Interface	SICSpro (RS422 for direct connection to process control unit (w/o indicator) Option: SICSpro-IDNet cable adaptor		
Update Rate	90 values per second		
Power Supply	6 to 18 VDC		
Operating Temperature	Compensated	-10°C to +40°C / 14°F to 104°F)	
	Operation	-20°C+65°C / -4°F+149°F	
Suitable Indicators	Safe Area: all SICSpro indicators, IDNet indicators: ID7, IND690, IND780, IND560		

Hygienic Accessories

Customize to Your Application



Closed platter

The closed platter is the standard option available for use with the PBD659 and PBA639. Choose between AISI 304 or AISI 316 Stainless Steel.



Sealed column

Using a completely sealed column with your indicator ensures that contaminants have nowhere to hide and makes cleaning even easier.



Open platter

Always keep the hygienic frame in view with this open platter AISI 316 stainless steel design. Easily spot contaminants and wash the platform down without having to remove the platter.



Open column

If you prefer easy access to all parts of the scale, choose the open column design. With rounded edges and large openings, cleaning is highly efficient.

Accessories Article # Designation Descriptior 30676281 Column open 330 mm / 13" Fits for plat 30676282 Column open 660 mm / 26" Fits for all j 30676283 Column open 900 mm / 35.4" Fits for all (hazardous 30676284 Column closed 330 mm / 13" Fits for plat 30676285 Column closed 660 mm / 26" Fits for all 30676286 Column closed 900 mm / 35.4" Fits for all I hazardous 30253326 Roller track 400 × 500 mm / Fits for 400 15.7" × 19.7" stainless steel platform. 30253328 Roller track 500 × 650 mm / Fits for 500 19.7" × 25.6" stainless steel platform. 30253330 Roller track 600 × 800 mm / Fits for 600 23.6" × 31.5" stainless steel platform. 30253327 Roller track 400 × 500 mm / Fits for 400 15.7" × 19.7" stainless steel form. 30253329 Roller track 500 × 650 mm / Fits for 500 19.7" × 25.6" stainless steel form. 30253331 Roller track 600 × 800 mm / Fits for 600 23.6" × 31.5" stainless steel form. 30640393 Roller track 400 × 500 mm / Fits for haze 15.7" × 19.7" stainless steel 30640394 Roller track 500 × 650 mm / Fits for haze 19.7" × 25.6" stainless steel 30640395 Roller track 600 × 800 mm / Fits for haze 23.6" × 31.5" stainless steel 72225939 Fits for 500 Stainless steel cart BC Fits for 600 72225940 Stainless steel cart CC 30676290 Front mount bracket Fit for ICS4 30676291 Fit for ICS68 Front mount bracket 22023696 Cable Extension (two M12 Plugs 6pin/6pin) 3 m Load cell ex 30024759 Cable Extension (two M12 Plugs 6pin/6pin) 10 m 22026963 ACC409 Adapter to



Choose from a variety of indicators

Minimize contamination risks with one of the metal keypad indicators. The low surface roughness and IP69k protection of these fully stainless steel indicators enable easy operation and cleaning, making them ideal for hygienically sensitive environments. The metal keypads are available as an option with ICS429 and ICS689.



APR331 label printer

The stainless steel housing and optional rubber gasket that closes the paper opening facilitate fast, thorough and easy cleaning to save time and reduce contamination risk in hygienic environments.

10

n	Picture
tform sizes. Fits for hazardous area.	L1 L1
platform size. Fits for hazardous area.	
platform sizes larger than A-Size. Fits for s area.	
tform sizes. Fits for hazardous area.	1 44
platform size. Fits for hazardous area.	
platform sizes larger than A-Size. Fits for s area	
0x500mm platform. Roll to short side of	
0x650mm platform. Roll to short side of	A Contraction
0x800mm platform. Roll to short side of	
0x500mm platform. Roll to long side of plat-	
0x650mm platform. Roll to long side of plat-	
0x800mm platform. Roll to long side of plat-	
zardous area.	
zardous area.	
zardous area.	
0 × 650 mm platform.	
0 × 800 mm platform.	
1_9 front mount.	
889 front mount.	
extension cables for the PBD659 platforms.	
convert SICSPro signal into IDNet.	
	L

Explore Our Service Solutions Tailored to Fit Your Equipment Needs

METTLER TOLEDO Service delivers resources to enhance your efficiency, performance and productivity by providing service packages that fit your operational needs, maximize your equipment lifetime, and protect your weighing solution scale investment.

www.mt.com/IND-Service

Start with

professional installation Installation services include support

for your unique production situation:

- Professional IQ/OQ/PQ/MQ documentation
- Initial calibration and confirmation of fit-for-purpose
- Hazardous area installations

Maintain accuracy over time

Receive professional guidance (GWP Verification[™]), including a routine testing plan that specifies four key factors to maximize your efficiency and ensure quality:

- Tests to perform
- Weights to use
- Testing frequency
- Tolerances to apply

Calibrate for quality and compliance

Add two years of preventive maintenance and repair coverage to protect your indicator or full system purchase

and achieve maximum productivity

and budget control.

Schedule

maintenance

Full preventative maintenance plans offer inspection, functional testing, and proactive replacement of worn parts.

Health inspections offer a full assessment of current condition with professional maintenance recommendations.

GWP[®]

Professional Accuracy Calibration Certificate (ACC) determines measurement uncertainty in use over the entire weighing range. Corresponding annexes give a clear pass/fail statement for specific tolerances applied, such as fit-for-purpose (GWP®), OIML R76, NTEP HB44, or further regulations.

www.mt.com/PBA639-PBD659

For more information



METTLER TOLEDO Group Industrial Division Local contact: www.mt.com/contacts

Subject to technical changes ©03/2023 METTLER TOLEDO. All rights reserved Document No. 30375778 A MarCom Industrial

Extend your warranty coverage

